

■PRACTICAL TIPS

♦ Make the cutting wheel to attain suitable water current, but can't touch the water pipe. The maximum cutting angle of the tool can come to 45°.

◆ Before connecting the tool with the electric source, please confirm the button of the switch is

in loose condition, the trigger of the switch can reset freely.

■ MAINTENANCE AND CARE

Unplug the tool from the socket before performing any works on the tool!

Tool requires no special maintenance, but after some time you must control the parts that are submitted to wear-and-tear under normal operating conditions. This includes the control and replacement of carbon brushes and grease in reducing gear housing. Take the tool to an authorized service centre.

 Keep the tool and supply cord clean. Keep ventilation slots clean and open. Wipe the surface of the tool with a soft cloth!

It is not allowed to use household cleaning agents that contain petrol, trichloroethylene, ammonia and chlorides. These substances corrode and damage plastic parts of the tool.

· Excessive sparking generally indicates the presence of dirt in the motor or abnormal wear on the

· In case of electric or mechanical failure, send the tool to a KEN authorized service centre for repair.

■ SERVICING AND REPAIRS

If servicing is required, contact one of our listed service centers. It is not allowed and dangerous to

perform any individual work on the tool. ♦ Have the tool repaired by authorized persons.

◆ Any repairs of the tool in unauthorized service centers is performed at own responsibility.

The owner of the tool is responsible for all works on the tool that were not performed in authorized service center, and therefore he losses the claim for guarantee.

■ WASTE DISPOSAL AND ENVIRONMENT PROTECTION

The machine, accessories and packing should be sorted for environmental-friendly recycling. Only for EC countries:

◆ Do not dispose of power tools into household waste!

According the European Guideline 2002/96/EC for Waste Electrical and Electronic Equipment and its implementation into national right, power tools that are no longer usable must be collected separately and disposed of in an environmentally correct manner.

SAFETY

The safety notes are as follow when use the marble cutter, please be sure to strictly follow, or may damage the tools or physical injury. · Please check there's no any fissure or damage of the cutting wheel, do not use a cutting wheel

for damaged, deformation or chips and cracks. - Do not use the wheel and the marble cutting wheel which not meet the instructions of

performance requirement

• Do use the inner and out flange and wrench equipped with the tool.

· As the additional protective measures of avoiding electric shock, please wear rubber gloves and rubber boots in operation. · Please check and confirm that the adjusting rotating button, the angle adjusting nut and the

hexagonal bolt that tightens the cutting wheel has been screwed tightly before cutting work. • Do not run when in the state of removal the fixed guard.

When start the tool, should check and ensure that the parts and cutting wheel or other items without any contact, do not start the cut off machine when the cutting wheel contact with the parts. Don't touch the rotating parts with hands.

· Please hold the tool tightly, and release the switch on time when appearing the cutting wheel decelerates suddenly or the processing object is clamped.

After the cut off machine power off, do not put down the cut off machine before the cutting wheel stop completely, and not allowed any outside force to stop the cutting wheel. - Before replace the cutting wheel adjust the cutting depth or repair the cut off machine, should

unplug the power plug, the cutting wheel in a static state. · Please use the twofold insulation electric cable which size is the same as the size of the tool when using the extended cable.

CAUTION:Hold tool by insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring or its own cord. Contact with a "live" wire will make

exposed metal parts of the tool "live" and shock the operator. 1) keep hands away from cutting area and rotating parts. Never reach underneath the material for any reason.

2)Keep handles dry,clean,and free from oil and grease. This will enable better control of the tool. 3) For additional protection against electric shock, be sure to wear rubber gloves and rubber boots when operating, and establishing leak circuit breaker.

4)Check the wheel carefully for cracks or damage before operation. Replace cracked or damaged wheel immediately.

5) Hold tool firmly. 6) Never attempt to cut with tool held upside down in a vice. This can lead to serious accidents, and is extremely dangerous.

7) Before setting the tool down after completing a cut, be sure that the wheel has come to a **complete stop.** Do not enforce to stop the wheel by any outside force.

8) Make sure the wheel is not in contact with the work piece before switching on. Wait until wheel attains full speed before commencing cutting.

9) No grinding disc is allowed to use on this tool. 10) Never use diamond wheel that its specifications are not specified in this manual.

11) Never use this tool without guard properly installed. 12)Always turn off and unplug the tool, and be sure the tool wheel has come to a complete stop

when changing wheel, adjusting the cutting depth and cutting angle or before repairing the tool. 13)The rated speed of the accessory must be at least equal to the maximum speed marked on

the power tool. Accessories running faster than their rated speed can break and fly apart.

608

19×1.5

ST5×65

ST4×16

M5×25

M5×8

Name

Bearing

Washer

O ring

Screw

Stator

Retainer

Small cap

Big cap

Switch

Screw

Screw

Screw

Power cord

Cord sleeve

Cord clamp

Capacitor

Connection

623033 Socket Wrench

54 623021 Whipping Wrench

WARNING! Read all instructions. Failure to follow all instructions listed below may result in electric shock, fire and /or serious injury. The term "power tool" in all of the warnings listed below refers to your mains operated power tool.

SAVE THESE INSTRUCTIONS.

1) WORK AREA

liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes. c) Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

a) Power tool plugs must match the outlet. Never modify the plugs in any way. Do not use any adapter plugs with earthed grounded power tools. Unmodified plugs and matching outlets will

b) Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and

c) **Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.

d) Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.

f) If operating a power tool in a damp location is unavoidable, use a residual current device (RCD)

protected supply. Use of an RCD reduces the risk of electric shock.

B) PERSONAL SAFETY

a) Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A

b) Use personal protective equipment. Always wear eye protection. protective equipment such as dust mask, no-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.

source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.

attached to a rotating part of the power tool may result in personal injury. e) Do not overreach. Keep proper footing and balance at all times. This enables better control of the

Dress properly. Do not wear loose clothing or jeweler. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jeweler or long hair can be caught in moving parts.

Original instruction

GENERAL SAFETY INSTRUCTIONS

a) Keep work area clean and well lit. Cluttered and dark areas invite accidents.

b) Do not operate power tools in explosive atmospheres, such as in the presence of flammable

refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.

Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool.

e) When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.

moment of inattention while operating power tools may result in serious personal injury.

c) Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power

d) Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left

g) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of these devices can reduce dust related hazards.

4) POWER TOOL USE AND CARE

a) Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.

b) Do not use the power tool if the switch does not turn it on and off. Any power tool that

cannot be controlled with the switch is dangerous and must be repaired. c) Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preven-

d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are danger-

tive safety measures reduce the risk of starting the power tool accidentally.

ous in the hands of untrained users. e) Maintain power tools. Check for misalignment or binding of moving parts, breakage of

parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges

are less likely to bind and are easier to control g) Use the power tool, accessories and tool bits etc. in accordance with these instructions,

taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation. h) Save all warnings and instructions for future reference. i) Recommendation: The tool always be supplied via residual current device with a rated residual

current of 30 mA or less.

Have your power tool serviced by a qualified repair person using only identical replace**ment parts.** This will ensure that the safety of the power tool is maintained.

IMPORTANT: Hold power tool by insulated gripping surfaces, when performing an operation where the cutting accessory may contact hidden wiring or its own cord. Cutting accessory contacting a "live" wire may make exposed metal parts of the power tool "live" and could give the operator an electric shock.

Thank you for buying a KEN power tool. Should you have any questions, vagueness or second thoughts about our products, we recommend you to contact our experts in Sales and Service Departments, who will advise you and help you find the right answers to the set questions. Please contact our local distributors or dealers directly.

TECHNICAL DATA Z1E-SH03-110 4100 Ф110×Ф20mm Size of Cutting Blade (Outer Diameter X Inner Diameter) AC 220-240V 50Hz Current Source Rated Input Power 1200W Loading Current 5.7A 12000/min Idling Rotational Speed Maximum Cutting Depth 34mm Socket Wrench 1PC Whipping Wrench 1PC Standard Spare Parts Carbon Brush 2PCS

Operating Handbook 1PC

OPERATION **◆**Assemble or Disassemble the Cutting Wheel

Use the whipping wrench to fix the outer flange, rotate the socket wrench clockwise to release the hexagonal bolt, disassemble the bolt, outer flange, and then the cutting wheel can be disassembled. When assembling the cutting wheel, make the marked direction on

♦Adjust Cutting Depth

bolt tightly. (Picture Three)

Release the butterfly bolt on the scale, and then

pull the base plate to move, adjust it to the

demanding depth and then screw the butterfly

the cutting wheel surface and the arrow direction on the tool to conform each other; it's OK to assemble it according to the above-said order oppositely. Please pay attention to screw the hexagonal bolt tightly. (Picture One, Picture

PARTS LIST of the Mod.4100 MARBLE CUTTER

113002

238001

319025

231005

273006

162079A

211003

242004

10 251005

11 243005

13 211067

14 276002

15 | 133031

16 336002

19 182016

20 234053

22 234003

23 333002

24 252001

25 | 136036

26 211023

28 442041

29 319024

276001

182010

12 | 143014 | Bearing sleeve

17 | 342002 | Paper washer

18 | 161002A | Front cover

Screw

Screw

Gear box

Bearing

Retainer

Big gear

Retainer

Bearing

Outer flange

Screw

Screw

O ring

Retainer

Pinion

Bearing

Key

Rotor

Retainer

Code

114001

321005

606-2Z | 36 | 314026A | Handle cover

335002

335003

40 313002A Motor housing

45 432001A Brush holder

46 | 431007B | Carbon brush

47 | 433002A | Brush cap

39 445001B

42 222002

48 411028

49 332006

318006

443008

6201-2Z | 43 | 231010

4×13 | 44 | 235001

M6×18 52 437001

629-2RS


3×10


30 211021


32 333015

34 441040

M4×15 | 33 | 221072








picture 3

◆Effective and Safe Cutting Methods

Hold the tool tightly, put the base plate on the object which is going to be cut and don't make it have any touch with the cutting wheel, then start up the tool and wait it to attain the maximum rotating speed. Move the tool along the surface of the project forward simply, please keep its level and go ahead slowly until the cutting work finished. Please keep the cutting line to be straight, and the speed of going ahead is in uniform. After the cutting work, please make the tool idle running one to two minutes to get rid of the dust of the inner

tool. (Picture Four)








◆Replace the Electric Brush The tool has set the electric brush limited

switch off condition. (Picture Five)

position equipment especially, please replace the electric brush if there's big sparks or the rotation stops during the running. Please use screwdriver to screw the lid of the electric brush and take out the wearing electric brush and install the new ones, and please use hands to try and confirm it can slide freely in the slot, and then install and screw the lid of the electric brush. Please replace two brushes at the same time, and use the specified "KEN" brand electric brush. (Picture Six)







picture 6

Marble Cutter KEN 4100 ZIE-SH03-110 ♦ KEN KEN Holding Co., Ltd. No.5 Xinrong Rd., Xinqiao Town, Songjiang District, Shanghai China

