




1982 - Planer



1982 - Planer

Item No	Part No	Description
1	222001	Tapping screw
2	315042	Rear cap
3	162080	Bearing cover
4	323014	Switch lock
5	151076	Spring
6	222002	Tapping screw
7	314138	Handle cover
8	445097	Switch
9	443008	Capacitor
10	318006	Cord clamp
11	332006	Cord sleeve
12	411015	Power cord
13	313117	Housing
14	441142	Field coil
15	211082	Bearing
16	319051	Spacer
17	442139	Armature
18	255007	Retainer
19	211217	Bearing
20	321067	Baffle plate
21	231017	Screw
22	326030	Belt protector
23	541473	Name plate
23	344001	Belt
24	182060	Small belt wheel
25	182059	Big belt wheel
26	221010	Tapping screw
27	168018	Cover board
28	334001	Rubber pin
29	211020	Bearing
30	234054	Hex bolt
31	110267	Knife Clamp
32	231097	Screw
33	110266	Blade adjusting plate
34	613009	Blade
35	160058	Cutter shaft
36	211033	Bearing
37	310272	Liftout plate
38	154028	Torsional spring
39	166018	Rear base
40	166017	Front base
41	343005	Foam mat
42	151089	Spring
43	310271	Small knob
44	432045	Brush holder

Item No	Part No	Description
45	431081	Carbon brush
46	433039	Brush holder cap
47	310270	Adjustment handwheel
48	540358	Label
49	221006	Tapping screw
50	326029	Dust protector
51	620069	Guide ruler
52	623054	Socket wrench
53	712066	Feeler block set
54	712067	knife board set