




6416 Impact Wrench

Position No	Part No	Description
1	110255	Sleeve
2	162074	Gearbox
3	136091	Big Gear
4	275009	Pin
5	143050	Big Steel Sleeve
6	253013	Retainer Ring
7	333064	O Ring
8	133086	Spindle
9	271010	Steel Ball
10	130001	Assault Block
11	151081	Spring
12	216001	Bearing
13	130002	Assault Shaft
14	136092	Pinion
15	212071	Needle Bearing
16	275010	Pin
17	211035	Bearing
18	163040	Medial Flange
19	211020	Bearing
20	442128	Armature
22	221076	Screw
23	436022	Lug
24	441127	Coil
25	211009	Bearing
26	331029	Bearing Sleeve
27	221048	Screw
28	314127	Handle Lid
30	445093	Switch
31	436023	Connecting Pin
32	443014	Capacitor
33	436068	Connecting Terminal
34	221047	Screw
35	318001	Cable Clamp
36	313127A	Motor Shell
37	411002	Power Cord
38	433036	Brush Cap
38	431068	Carbon Brush

Position No	Part No	Description
40	432044	Brush Holder
41	435003	Rod Spring
42	116030	Bearing Clamp
43	221077	Tapping Screw
44	332006	Cable Sleeve
45	242017	Washer
46	241002	Spring Washer
47	232003	Socket Head Cap Screw