




1982 Planer

Position No	Part No	Description
1	222001	Screw
2	315042	Rear Cover
3	162080	Bearing Cover
4	323014	Switch Button
5	151076	Spring
6	222002	Tapping Screw
7	314138	Handle Lid
8	445097	Switch
9	443008	Capacitor
10	318006	Cable Clamp
11	332006	Cable Sleeve
12	411015	Power Cord
13	313117	Motor Shell
14	441142	Coil
15	211082	Bearing
16	319051	Plastic Ring
17	442139	Armature
18	255007	Retainer Ring
19	211217	Bearing
20	321067	Wind Deflector
21	231017	Screw
22	3260301	Belt Protector
23	344008	Ribbed Belt
24	182060	Small Belt Pulley
25	182059	Big Belt Pulley
26	221010	Tapping Screw
27	168018	Side Cover
28	334001	Rubber Column
29	211020	Bearing
30	234054	Hex Bolt
31	110267	Knife Holder
32	231097	Screw
33	110266	Adjusting Panel
34	613009	Knife
35	160058	Knife Shaft
36	211033	Bearing
37	310272	Lifting Block
38	154028	Torsional Spring
39	166018	Rear Soleplate

Position No	Part No	Description
40	166017	Front Base
41	343005	Washer
42	151089	Spring
43	310271	Small Knob
44	4320451	Brush Holder
45	431081	Carbon Brush Assy.
46	4330391	Brush Cap
47	310270	Adjustment Handwheel
48	540358	Depth Label
49	221006	Tapping Screw
50	326029	Chip Protector
51	620069	Guide Gauge
52	623054	Socket Wrench
53	712066	Feeler Block Assy.
54	712067	Knife Holder Kit
55	310273	Tool Reference Plate
56	310274	Tool Plate
57	231026	Screw
58	310233	Knob
59	239012	Bolt
60	310275	Upper Knife Holder
61	310276	Middle Knife Holder
62	310277	Bottom Knife Holder